

=== COVER PAGE ===

TO: _____

FROM: SANDRA ROSS

FAX: 14177772311

TEL: 14177772311

COMMENT:

***** HELP LIST *****

<STEPS TO SET A MENU SELECTION>

- 1) PRESS THE MENU/SET KEY.
- 2) USING UP OR DOWN KEYS SELECT THE MAIN MENU, AND THEN PRESS THE MENU/SET KEY TO ENTER IT.
- 3) USING UP OR DOWN KEYS SELECT THE MENU SELECTION, AND THEN PRESS THE MENU/SET KEY TO ENTER IT.
- 4) USING UP OR DOWN KEYS SELECT THE OPTION YOU WANT, AND THEN PRESS THE MENU/SET KEY TO ENTER IT.
- 5) PRESS STOP/EXIT KEY TO EXIT

NOTE: MAKE SURE YOU FIRST SET:
 DATE/TIME (MENU, 1, 1)
 STATION ID: (MENU, 1, 2)
 TONE/PULSE (MENU, 1, 5)

<REPORTS KEY MENU>

1. HELP LIST
2. AUTO DIAL
3. FAX ACTIVITY
4. TRANSMISSION
5. TEL. INDEX
6. USER SETTINGS
7. MEMORY STATUS

<MENU SELECTION TABLE>

MAIN MENU	MENU SELECTIONS	OPTIONS
1. INITIAL SETUP	--1. DATE/TIME 2. STATION ID 3. BEEPER 4. VOLUME AMPLIFY 5. TONE/PULSE	(FAX/TEL/NAME) (OFF/LOW/HIGH) (OFF, ON: PERMANENT/TEMPORARY) (TONE/PULSE)
2. SETUP RECEIVE	--1. RING DELAY 2. F/T RING TIME 3. EASY RECEIVE 4. REMOTE CODE 5. REDUCTION 6. PAPER 7. POLLING RX	(00/01/02/03/04) (20/30/40/70) (ON/SEMI/OFF) (ON/OFF, SET CODE) (AUTO/100%/93%/87%/75%) (LETTER/LEGAL/A4) (ON/OFF)
3. SETUP SEND	--1. COVERPG SETUP 2. COVERAGE MSG 3. CONTRAST 4. RESOLUTION 5. OVERSEAS MODE 6. CALL RESERVE 7. DELAYED FAX 8. POLLED TX	(NEXT FAX ONLY/ON/OFF/ PRINT SAMPLE) (AUTO/S. LIGHT/S. DARK) (STD/FINE/S. FINE/PHOTO) (ON/OFF) (ON/OFF/PRINT SAMPLE) (ON/OFF)
4. CANCEL JOB		
5. INTERRUPT		
6. SET AUTO DIAL	--1. ONE-TOUCH DIAL 2. SPEED-DIAL 3. SETUP GROUPS	
7. SETUP REPORTS	--1. TRANSMISSION 2. ACT. INTERVAL	(ON/OFF) (5H/12H/24H/2D/4D/7D/OFF)
8. REMOTE FAX OPT	--1. FAX FWD/PAGING 2. FAX STORAGE 3. REMOTE ACCESS 4. PRINT FAX	(OFF/FAX FORWARD/PAGING) (ON/OFF)
9. TEL SERVICE	--1. DISTINCTIVE 2. CALLER ID	(ON/OFF/SET)

1-888-473

2903 <KEY OPERATIONS>

MENU/SET	*ACCESS THE MENU AND PROGRAMMING MODE. *GO TO THE NEXT MENU LEVEL. *ACCEPT AN OPTION TO CHANGE A SETTING.
UP↑ OR DOWN↓	*SCROLL THROUGH THE MENU LEVEL. *ADJUST THE RING VOLUME.
LEFT←	*GO BACK TO THE PREVIOUS MENU LEVEL. *LOOK UP NUMBERS STORED IN THE DIALING MEMORY ALPHABETICALLY.
RIGHT→	*GO TO THE NEXT MENU LEVEL. *LOOK UP NUMBERS STORED IN THE DIALING MEMORY ALPHABETICALLY.
FAX START	*START AN OPERATION, SUCH AS SENDING A FAX.
RESOLUTION	*SET THE RESOLUTION WHEN YOU SEND A FAX.
RECEIVE MODE	*SELECT HOW THE MACHINE HANDLES INCOMING CALLS.
STOP/EXIT	*EXIT THE MENU.
SEARCH/ SPEED DIAL	*LOOK UP NUMBERS STORED IN THE DIALING MEMORY. *DIAL STORED SPEED-DIAL NUMBERS BY PRESSING # AND A TWO-DIGIT NUMBER.
REDIAL/PAUSE	*REDIAL THE LAST NUMBER CALLED. *INSERT A PAUSE IN AUTO DIAL NUMBERS.

<FAX RECEIVE MODE>

MANUAL MODE	FAX MODE	FAX/TEL MODE	TAD MODE
*FOR DEDICATED TELEPHONE USE ONLY.	*FOR DEDICATED FAX USE ONLY.	*FOR BOTH FAX AND TELEPHONE USE.	*WHEN CONNECTING AN EXTERNAL TELEPHONE ANSWERING DEVICE.