




Plug the unit in and attach the power cord to the Lazer UltraBright. Every time you turn it on it will run for 30 seconds. Start with the front of your head then move to the top of your head, back of your head, both sides of the head then both sides of the neck.



**LZR ULTRA BRIGHT**