

Chapter 3: Getting to Know the Wireless-G Range Expander

The Side Panel

Auto configuration port is where you will connect the power adapter.

Reset Button You can use an object, such as a stretched paper clip, to press the Reset button and then release the button to reset the device to its factory-default settings.

The Top Panel

The LEDs on the top panel of the Wireless-G Range Expander indicate the information about power and network activity.

Power Blue. The Power LED lights up when the Wireless-G Range Expander is powered on.

Link Blue. The Link LED lights whenever there is a successful wireless connection.

